



# ESP8266 AT Instruction Set

**Version 1.5**

Espressif Systems IOT Team

Copyright © 2016



### **Disclaimer and Copyright Notice**

Information in this document, including URL references, is subject to change without notice.

THIS DOCUMENT IS PROVIDED AS IS WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. All liability, including liability for infringement of any proprietary rights, relating to use of information in this document is disclaimed. No licenses express or implied, by estoppel or otherwise, to any intellectual property rights are granted herein.

The WiFi Alliance Member Logo is a trademark of the WiFi Alliance.

All trade names, trademarks and registered trademarks mentioned in this document are property of their respective owners, and are hereby acknowledged.

Copyright © 2016 Espressif Systems. All rights reserved.



# Table of Contents

|   |           |
|---|-----------|
| <b>1. Preambles .....</b>                               | <b>6</b>  |
| 1.1. User-define AT commands .....                      | 6         |
| 1.2. Download AT firmware into Flash .....              | 7         |
| 1. 4Mbit Flash.....                                     | 7         |
| 2. 8Mbit Flash.....                                     | 7         |
| 3. 16Mbit Flash, map: 512KB + 512KB .....               | 8         |
| 4. 16Mbit Flash, map: 1024KB + 1024KB .....             | 8         |
| 5. 32Mbit Flash, map: 512KB + 512KB .....               | 8         |
| 6. 32Mbit Flash, map: 1024KB + 1024KB .....             | 9         |
| <b>2. Command Description .....</b>                     | <b>10</b> |
| <b>3. Basic AT Command Set .....</b>                    | <b>11</b> |
| 3.1. Overview .....                                     | 11        |
| 3.2. Commands .....                                     | 12        |
| 1. AT – Test AT startup .....                           | 12        |
| 2. AT+RST – Restart module .....                        | 12        |
| 3. AT+GMR – View version info.....                      | 12        |
| 4. AT+GSLP – Enter deep-sleep mode .....                | 13        |
| 5. ATE – AT commands echo.....                          | 13        |
| 6. AT+RESTORE – Factory reset.....                      | 13        |
| 7. AT+UART – UART configuration .....                   | 14        |
| 8. AT+UART_CUR – current UART configuration .....       | 15        |
| 9. AT+UART_DEF – default UART configuration.....        | 16        |
| 10. AT+SLEEP – sleep mode .....                         | 17        |
| 11. AT+RFPOWER – set maximum value of RF TX Power.....  | 17        |
| 12. AT+RFVDD – set RF TX Power according to VDD33 ..... | 18        |
| <b>4. WiFi Functions Overview .....</b>                 | <b>19</b> |
| 4.1. Commands .....                                     | 21        |
| 1. AT+CWMODE – WiFi mode .....                          | 21        |
| 2. AT+CWMODE_CUR – current WiFi mode .....              | 22        |



|     |  |    |
|-----|--|----|
| 3.  | AT+CWMODE_DEF – default WiFi mode .....  | 23 |
| 4.  | AT+CWJAP – Connect to AP.....  | 24 |
| 5.  | AT+CWJAP_CUR – Connect to AP , for current .....   | 25 |
| 6.  | AT+CWJAP_DEF – Connect to AP , save as default.....  | 26 |
| 7.  | AT+CWLAPOPT – Set configuration for command AT+CWLAP .....                                       | 27 |
| 8.  | AT+CWLAP – List available APs .....  | 28 |
| 9.  | AT+CWQAP – Disconnect from AP.....   | 29 |
| 10. | AT+CWSAP – Configuration of softAP mode .....  | 29 |
| 11. | AT+CWSAP_CUR – Current config of softAP mode.....  | 30 |
| 12. | AT+CWSAP_DEF – Default config of softAP mode.....  | 31 |
| 13. | AT+CWLIF – IP of stations .....  | 32 |
| 14. | AT+CWDHCP – Enable/Disable DHCP .....  | 33 |
| 15. | AT+CWDHCP_CUR – Enable/Disable DHCP .....  | 34 |
| 16. | AT+CWDHCP_DEF – Enable/Disable DHCP and save to Flash .....                                      | 35 |
| 17. | AT+CWDHCPS_CUR – Set the IP address allocated by ESP8266 soft-AP DHCP, cannot save to flash..... | 36 |
| 18. | AT+CWDHCPS_DEF – Set the IP address allocated by ESP8266 soft-AP DHCP, save to flash.....        | 37 |
| 19. | AT+CWAUTOCONN – Auto connect to AP or not.....   | 37 |
| 20. | AT+CIPSTAMAC – Set MAC address of station .....  | 38 |
| 21. | AT+CIPSTAMAC_CUR – Set MAC address of station .....  | 39 |
| 22. | AT+CIPSTAMAC_DEF – Set MAC address of station, save as default ....                              | 39 |
| 23. | AT+CIPAPMAC – Set MAC address of softAP .....  | 40 |
| 24. | AT+CIPAPMAC_CUR – Set MAC address of softAP .....  | 40 |
| 25. | AT+CIPAPMAC_DEF – Set MAC address of softAP and save as default .                                | 41 |
| 26. | AT+CIPSTA – Set IP address of station.....   | 42 |
| 27. | AT+CIPSTA_CUR – Set IP address of station .....  | 43 |
| 28. | AT+CIPSTA_DEF – Set IP address of station and save as default .....                              | 44 |
| 29. | AT+ CIPAP – Set IP address of softAP .....   | 45 |
| 30. | AT+CIPAP_CUR – Set IP address of softAP .....  | 46 |
| 31. | AT+CIPAP_DEF – Set IP address of softAP, save as default .....                                   | 47 |
| 32. | AT+CWSTARTSMART – Start SmartConfig .....  | 48 |
| 33. | AT+CWSTOPSMART – stop SmartConfig .....  | 48 |



|   |           |
|---|-----------|
| 34. AT+CWSTARTDISCOVER – Start the mode that ESP8266 can be found by WeChat ...     | 49        |
| 35. AT+CWSTOPDISCOVER – Stop the mode that ESP8266 can be found by WeChat .....     | 49        |
| 36. AT+WPS – Set WPS function .....   | 50        |
| 37. AT+MDNS – Set MDNS function .....   | 50        |
| <b>5. TCP/IP Related AT Commands .....</b>  | <b>51</b> |
| 5.1. Overview .....   | 51        |
| 5.2. TCP/IP .....   | 52        |
| 1. AT+CIPSTATUS – Check network connection status .....                             | 52        |
| 2. AT+CIPSTART – Establish TCP connection, UDP transmission or SSL connection ..... | 52        |
| 3. AT+CIPSSLSIZE – Set the size of SSL buffer .....                                 | 54        |
| 4. AT+CIPSEND – Send data .....   | 55        |
| 5. AT+CIPSENDEX – Send data .....   | 56        |
| 6. AT+CIPSENDDBUF – Write data into TCP-send-buffer.....                            | 57        |
| 7. AT+CIPBUFSTATUS – Check status of TCP-send-buffer .....                          | 58        |
| 8. AT+CIPCHECKSEQ – Check if specific segment sent successfully or not              | 59        |
| 9. AT+CIPBUFRESET – Reset segment ID count.....                                     | 59        |
| 10. AT+CIPCLOSE – Close TCP, UDP or SSL connection.....                             | 60        |
| 11. AT+CIFSR – Get local IP address .....   | 60        |
| 12. AT+CIPMUX – Enable multiple connections .....                                   | 61        |
| 13. AT+CIPSERVER – Configure as TCP server .....                                    | 62        |
| 14. AT+CIPMODE – Set transfer mode .....  | 63        |
| 15. AT+SAVETRANSLINK – Save transparent transmission link to Flash .....            | 64        |
| 16. AT+CIPSTO – Set TCP server timeout .....  | 65        |
| 17. AT+PING – Function Ping .....   | 65        |
| 18. AT+CIUPDATE – Update through network .....                                      | 66        |
| 19. AT+CIPDINFO – Show remote IP and port with “+IPD” .....                         | 66        |
| 20. +IPD – Receive network data .....   | 67        |
| <b>6. Appendix.....</b>   | <b>68</b> |
| <b>7. Q&amp;A.....</b>  | <b>69</b> |



## 1. Preambles

AT commands set is divided into: Basic AT commands, WiFi related AT commands, TCP / IP AT commands.

### 1.1. User-define AT commands

Please use only letters when naming user-define AT commands, do not name it with other characters or numbers.


AT is based on esp\_iot\_sdk, Espressif Systems AT commands are provided in libat.a. In the example of \esp\_iot\_sdk\examples\at\user\user\_main.c, ways are delivered on how to implement a self-defined AT Command, "AT+TEST".

The structure, **at\_funcationType**, is used to define four types of a command, e.g. "AT+TEST".

| Definition         | Type    | Description   |                                      |
|--------------------|---------|---|--------------------------------------|
| <b>at_testCmd</b>  | Test    | AT Command  | AT+TEST=?                            |
|                    |         | Registered Callback In Example  | at_testCmdTest                       |
|                    |         | Function Design   | Return the value range of parameters |
|                    |         | If at_testCmd is registered as NULL, there will be no testing command.  |                                      |
| <b>at_queryCmd</b> | Query   | AT Command  | AT+TEST?                             |
|                    |         | Registered Callback In Example  | at_queryCmdTest                      |
|                    |         | Function Design   | Return the current value             |
|                    |         | If at_queryCmd is registered as NULL, there will be no query command.   |                                      |
| <b>at_setupCmd</b> | Set     | AT Command  | AT+TEST=parameter1,parameter2,...    |
|                    |         | Registered Callback In Example  | at_setupCmdTest                      |
|                    |         | Function Design   | Set configuration                    |
|                    |         | If at_setupCmd is registered as NULL, there will be no setup command.   |                                      |
| <b>at_exeCmd</b>   | Execute | AT Command  | AT+TEST                              |
|                    |         | Registered Callback In Example  | at_exeCmdTest                        |
|                    |         | Function Design   | Execute an action                    |
|                    |         | If at_exeCmd is registered as NULL, there will be no execution command. |                                      |



Copy all files in folder "at" to folder "app" in `esp_iot_sdk` if users need to compile AT.



Introduction of compilation can refer to documentation "2A-ESP8266\_IOT\_SDK\_User\_Manual".

## 1.2. Download AT firmware into Flash

Refer to `esp_iot_sdk\bin\at\readme.txt` on how to download AT firmware into Flash.

Please use Espressif official Flash download tool and select corresponding Flash size while downloading.

Espressif official Flash download tool: <http://bbs.espressif.com/viewtopic.php?f=5&t=433>

### 1. 4Mbit Flash

With the release of ESP8266\_NONOS\_SDK\_V1.5.0, AT\_V0.51, AT firmware needs 8Mbit or larger Flash size. Please do not use 4Mbit Flash any more.

### 2. 8Mbit Flash

If the Flash size is 8Mbit or larger, users can use boot mode which support upgrade AT firmware through WiFi by command "AT+CIUPDATE". Use Espressif Flash download tool and select Flash size : 8Mbit.

| bin                              | Address | Description   |
|----------------------------------|---------|---|
| <b>esp_init_data_default.bin</b> | 0xFC000 | Optional. Stores default RF parameter values.                     |
| <b>blank.bin</b>                 | 0x7E000 | Initialize Flash user parameter area, more details in Appendix.   |
| <b>blank.bin</b>                 | 0xFE000 | Initialize Flash system parameter area, more details in Appendix. |
| <b>boot.bin</b>                  | 0x00000 | In \bin\at  |
| <b>user1.1024.new.2.bin</b>      | 0x01000 | In \bin\at\512+512  |



### 3. 16Mbit Flash, map: 512KB + 512KB

Use Espressif Flash download tool and select Flash size : 16Mbit.

| bin                              | Address  | Description   |
|----------------------------------|----------|---|
| <b>esp_init_data_default.bin</b> | 0x1FC000 | Optional. Stores default RF parameter values.                     |
| <b>blank.bin</b>                 | 0x7E000  | Initialize Flash user parameter area, more details in Appendix.   |
| <b>blank.bin</b>                 | 0x1FE000 | Initialize Flash system parameter area, more details in Appendix. |
| <b>boot.bin</b>                  | 0x00000  | In \bin\at  |
| <b>user1.1024.new.2.bin</b>      | 0x01000  | In \bin\at\512+512  |

### 4. 16Mbit Flash, map: 1024KB + 1024KB

Use Espressif Flash download tool and select Flash size : 16Mbit-C1.

| bin                              | Address  | Description   |
|----------------------------------|----------|---|
| <b>esp_init_data_default.bin</b> | 0x1FC000 | Optional. Stores default RF parameter values.                     |
| <b>blank.bin</b>                 | 0xFE000  | Initialize Flash user parameter area, more details in Appendix.   |
| <b>blank.bin</b>                 | 0x1FE000 | Initialize Flash system parameter area, more details in Appendix. |
| <b>boot.bin</b>                  | 0x00000  | In \bin\at  |
| <b>user1.2048.new.5.bin</b>      | 0x01000  | In \bin\at\1024+1024  |

### 5. 32Mbit Flash, map: 512KB + 512KB

Use Espressif Flash download tool and select Flash size : 32Mbit.

| bin                              | Address  | Description   |
|----------------------------------|----------|---|
| <b>esp_init_data_default.bin</b> | 0x3FC000 | Optional. Stores default RF parameter values.                     |
| <b>blank.bin</b>                 | 0x7E000  | Initialize Flash user parameter area, more details in Appendix.   |
| <b>blank.bin</b>                 | 0x3FE000 | Initialize Flash system parameter area, more details in Appendix. |
| <b>boot.bin</b>                  | 0x00000  | In \bin\at  |
| <b>user1.1024.new.2.bin</b>      | 0x01000  | In \bin\at\512+512  |



## 6. 32Mbit Flash, map: 1024KB + 1024KB

Use Espressif Flash download tool and select Flash size : 32Mbit-C1.

| bin                              | Address  | Description   |
|----------------------------------|----------|---|
| <b>esp_init_data_default.bin</b> | 0x3FC000 | Optional. Stores default RF parameter values.                     |
| <b>blank.bin</b>                 | 0xFE000  | Initialize Flash user parameter area, more details in Appendix.   |
| <b>blank.bin</b>                 | 0x3FE000 | Initialize Flash system parameter area, more details in Appendix. |
| <b>boot.bin</b>                  | 0x00000  | In \bin\at  |
| <b>user1.2048.new.5.bin</b>      | 0x01000  | In \bin\at\1024+1024  |

### Notes:

- Please make sure that correct BIN ([/esp\\_iot\\_sdk/bin/at](#)) is already in the chip (ESP8266) before the AT commands listed in this documentation can be used.
- AT has already taken priority 0 and 1 of [system\\_os\\_task](#), so only one task of priority 2 is allowed to set up by user.
- AT returns messages below to show status of Wi-Fi connection of ESP8266 station
  - WiFi CONNECTED - Wi-Fi connected
  - WiFi GOT IP - ESP8266 station got IP from AP
  - WiFi DISCONNECT - Wi-Fi disconnected





## 2. Command Description

Each Command set contains four types of AT commands.

| Type    | Command Format | Description  |
|---------|----------------|--|
| Test    | AT+<x>=?       | Query the Set command or internal parameters and its range values. |
| Query   | AT+<x>?        | Returns the current value of the parameter.                        |
| Set     | AT+<x>=<...>   | Set the value of user-defined parameters in commands and run.      |
| Execute | AT+<x>         | Runs commands with no user-defined parameters.                     |

Notes:

1. Not all AT Command has four commands.
2. [] = default value, not required or may not appear
3. String values require double quotation marks, for example:  
`AT+CWSAP="ESP756290","21030826",1,4`
4. Baudrate = 115200
5. AT Commands has to be capitalized, and end with "/r/n"





## 3. Basic AT Command Set

### 3.1. Overview

The ESP8266 wireless WiFi modules can be driven via the serial interface using the standard AT commands. Here is a list of some basic AT commands that can be used.

| Basic       |   |
|-------------|---|
| Command     | Description                               |
| AT          | Test AT startup                           |
| AT+RST      | Restart module                            |
| AT+GMR      | View version info                         |
| AT+GSLP     | Enter deep-sleep mode                     |
| ATE         | AT commands echo or not                   |
| AT+RESTORE  | Factory Reset                             |
| AT+UART     | UART configuration, <b>[@deprecated]</b>  |
| AT+UART_CUR | UART current configuration                |
| AT+UART_DEF | UART default configuration, save to flash |
| AT+SLEEP    | Sleep mode                                |
| AT+RFPOWER  | Set maximum value of RF TX Power          |
| AT+RFVDD    | Set RF TX Power according to VDD33        |



## 3.2. Commands

### 1. AT – Test AT startup

The type of this command is "executed". It's used to test the setup function of your wireless WiFi module.

| AT - Test AT startup |      |
|----------------------|------|
| Response             | OK   |
| Parameters           | null |

### 2. AT+RST – Restart module

The type of this command is "executed". It's used to restart the module.

| AT+RST - Restart module |      |
|-------------------------|------|
| Response                | OK   |
| Parameters              | null |

### 3. AT+GMR – View version info

This AT command is used to check the version of AT commands and SDK that you are using, the type of which is "executed".

| AT+GMR - View version info |   |
|----------------------------|---|
| Response                   | <AT version info><br><SDK version info><br><compile time><br><br>OK   |
| Parameters                 | <AT version info> information about AT version<br><SDK version info> information about SDK version<br><compile time> time of the bin was compiled |



#### 4. AT+GSLP – Enter deep-sleep mode

This command is used to invoke the deep-sleep mode of the module, the type of which is "set". A minor adjustment has to be made before the module enter this deep sleep mode, i.e., connect XPD\_DCDC with EXT\_RSTB via **0 ohm resistor**.

| AT+GSLP=<time>    |  |
|-------------------|--|
| <b>Response</b>   | <time><br>OK   |
| <b>Parameters</b> | The time unit of <time> is ms.<br>ESP8266 will wake up after deep sleep <time> ms. |

#### 5. ATE – AT commands echo

This command ATE is an AT trigger command echo. It means that entered commands can be echoed back to the sender when ATE command is used. Two parameters are possible. The command returns "OK" in normal cases and "ERROR" when a parameter other than 0 or 1 was specified.

| ATE - AT commands echo |   |
|------------------------|---|
| <b>Response</b>        | OK  |
| <b>Parameters</b>      | ATE0: Switch echo off<br>ATE1: Switch echo on |

#### 6. AT+RESTORE – Factory reset

This command is used to reset all parameters saved in flash (according to appendix), restore the factory default settings of the module. The chip will be restarted when this command is executed.

| AT+RESTORE - Factory reset |  |
|----------------------------|--|
| <b>Response</b>            | OK   |
| <b>Notes</b>               | Restore factory default settings.<br><b>The chip will restart.</b> |



## 7. AT+UART – UART configuration

This command sets the UART configuration and writes the new configuration to the flash. It is stored as the default parameter and will also be used as the default baudrate henceforth. [THIS API IS DEPRECATED.]

| <b>AT+UART=&lt;baudrate&gt;,&lt;databits&gt;,&lt;stopbits&gt;,&lt;parity&gt;,&lt;flow control&gt;</b> |  |   |
|---|--|---|
| <b>This command is deprecated, please use AT+UART_CUR or AT+UART_DEF instead.</b>                     |  |   |
| <b>Example</b>  | AT+UART=115200,8,1,0,3   |   |
| <b>Response</b>   | OK   |   |
| <b>Parameters</b>   | <baudrate>   | Baudrate range: 110 to 115200*40 (4.608 Mega)   |
|   | <databits>   | 5: 5 bits data<br>6: 6 bits data<br>7: 7 bits data<br>8: 8 bits data                    |
|   | <stopbits>   | 1: 1 bit stop bit<br>2: 1.5 bit stop bit<br>3: 2 bit stop bit                           |
|   | <parity>   | 0: None<br>1: Odd<br>2: EVEN  |
|   | <flow control>   | 0: disable flow control<br>1: enable RTS<br>2: enable CTS<br>3: enable both RTS and CTS |
| <b>Notes</b>  | <ul style="list-style-type: none"><li>This configuration will also store the baudrate as the default rate in the user parameter area in the Flash for boot up.</li><li>Flow control needs hardware support: MTCK is UART0 CTS and MTDO is UART0 RTS.</li></ul> |   |



## 8. AT+UART\_CUR – current UART configuration

This command sets the current UART configuration; it does not write to the flash. Hence there is no change in the default baudrate.

| AT+UART_CUR=<baudrate>,<databits>,<stopbits>,<parity>,<flow control> |  |   |
|--|--|---|
| Example  | AT+UART_CUR=115200,8,1,0,3   |   |
| Response   | OK   |   |
| Parameters   | <baudrate>   | Baudrate range: 110 to 115200*40 (4.608 Mega)   |
|  | <databits>   | 5: 5 bits data<br>6: 6 bits data<br>7: 7 bits data<br>8: 8 bits data                    |
|  | <stopbits>   | 1: 1 bit stop bit<br>2: 1.5 bit stop bit<br>3: 2 bit stop bit                           |
|  | <parity>   | 0: None<br>1: Odd<br>2: EVEN  |
|  | <flow control>   | 0: disable flow control<br>1: enable RTS<br>2: enable CTS<br>3: enable both RTS and CTS |
| Notes  | <ul style="list-style-type: none"><li>This configuration will <b>NOT</b> store in the Flash.</li><li>Flow control needs hardware support: MTCK is UART0 CTS and MTDO is UART0 RTS.</li></ul> |   |



## 9. AT+UART\_DEF – default UART configuration

This command sets the UART configuration and save it to flash. It is stored as the default parameter and will also be used as the default baudrate henceforth.

| AT+UART_DEF=<baudrate>,<databits>,<stopbits>,<parity>,<flow control> |  |   |
|--|--|---|
| <b>Example</b>   | AT+UART_DEF=115200,8,1,0,3   |   |
| <b>Response</b>  | OK   |   |
| <b>Parameters</b>  | <baudrate>   | Baudrate range: 110 to 115200*40 (4.608 Mega)   |
|  | <databits>   | 5: 5 bits data<br>6: 6 bits data<br>7: 7 bits data<br>8: 8 bits data                    |
|  | <stopbits>   | 1: 1 bit stop bit<br>2: 1.5 bit stop bit<br>3: 2 bit stop bit                           |
|  | <parity>   | 0: None<br>1: Odd<br>2: EVEN  |
|  | <flow control>   | 0: disable flow control<br>1: enable RTS<br>2: enable CTS<br>3: enable both RTS and CTS |
| <b>Notes</b>   | <ul style="list-style-type: none"><li>This configuration will be stored in user parameter area in the Flash for boot up.</li><li>Flow control needs hardware support: MTCK is UART0 CTS and MTDO is UART0 RTS.</li></ul> |   |



## 10. AT+SLEEP – sleep mode

This command sets ESP8266 sleep mode. It can only be used in station mode, default to be modem-sleep mode .

| AT+SLEEP - sleep mode |  |
|-----------------------|--|
| Command               | AT+SLEEP?  |
| Response              | +SLEEP : <sleep mode><br>OK  |
| Parameters            | <sleep mode><br>0 : disable sleep mode<br>1 : light-sleep mode<br>2 : modem-sleep mode |
| Command               | AT+SLEEP=<sleep mode>  |
| Response              | OK   |
| Parameters            | The same as above.   |

## 11. AT+RFPOWER – set maximum value of RF TX Power

This command sets the maximum value of ESP8266 RF TX power, it is not precise.

| AT+RFPOWER - set RF TX Power |   |
|------------------------------|---|
| Example                      | AT+RFPOWER=50   |
| Command                      | AT+RFPOWER=<TX power>   |
| Response                     | OK  |
| Parameters                   | <TX power> maximum value of RF TX power, range 0 ~ 82, unit:0.25dBm |



## 12. AT+RFVDD – set RF TX Power according to VDD33

This command sets ESP8266 RF TX power according to VDD33. To get the power voltage of ESP8266 VDD3P3, TOUT pin has to be suspended. TOUT pin has to be suspended to measure VDD33.

| AT+RFVDD - set RF TX power according to VDD33 |  |
|---|--|
| <b>Command</b>                                | <b>AT+RFVDD?</b>   |
| <b>Response</b>                               | +RFVDD:<VDD33><br>OK   |
| <b>Parameters</b>                             | <VDD33> power voltage of ESP8266 VDD33, unit: 1/1024 V<br>TOUT pin has to be suspended to measure VDD33. |
| <b>Command</b>                                | <b>AT+RFVDD=&lt;VDD33&gt;</b>  |
| <b>Response</b>                               | OK   |
| <b>Parameters</b>                             | <VDD33> power voltage of ESP8266 VDD33, range [1900, 3300]   |
| <b>Command</b>                                | <b>AT+RFVDD</b>  |
| <b>Response</b>                               | OK   |
| <b>Note</b>                                   | "AT+RFVDD" will automatically set RF TX power according to VDD33.<br>TOUT pin has to be suspended.       |



## 4. WiFi Functions Overview

| Wi-Fi Connectivity Functions Invoked by AT commands |  |
|---|--|
| Command   | Description  |
| AT+CWMODE   | Wi-Fi mode (sta/AP/sta+AP) , <b>[@deprecated]</b>            |
| AT+CWMODE_CUR                                       | Wi-Fi mode (sta/AP/sta+AP)<br>Won't save to Flash            |
| AT+CWMODE_DEF                                       | Wi-Fi default mode (sta/AP/sta+AP)<br>Save to Flash          |
| AT+CWJAP  | Connect to AP, <b>[@deprecated]</b>                          |
| AT+CWJAP_CUR  | Connect to AP, won't save to Flash                           |
| AT+CWJAP_DEF  | Connect to AP, save to Flash                                 |
| AT+CWLAPOPT   | Set the configuration of command AT+CWLAP                    |
| AT+CWLAP  | Lists available APs  |
| AT+CWQAP  | Disconnect from AP   |
| AT+CWSAP  | Set configuration of ESP8266 soft-AP<br><b>[@deprecated]</b> |
| AT+CWSAP_CUR  | Set configuration of ESP8266 soft-AP<br>Won't save to Flash. |
| AT+CWSAP_DEF  | Set configuration of ESP8266 soft-AP<br>Save to Flash.       |
| AT+CWLIF  | Get station's IP which is connected to ESP8266 soft-AP       |
| AT+CWDHCP   | Enable/Disable DHCP, <b>[@deprecated]</b>                    |
| AT+CWDHCP_CUR                                       | Enable/Disable DHCP, won't save to Flash                     |
| AT+CWDHCP_DEF                                       | Enable/Disable DHCP, save to Flash                           |
| AT+CWDHCPS_CUR                                      | Set IP range of DHCP server, won't save to Flash             |
| AT+CWDHCPS_DEF                                      | Set IP range of DHCP server, save to Flash                   |
| AT+CWAUTOCONN                                       | Connect to AP automatically when power on                    |



|                    |  |
|--------------------|--|
| AT+CIPSTAMAC       | Set MAC address of ESP8266 station<br>[@deprecated]        |
| AT+CIPSTAMAC_CUR   | Set MAC address of ESP8266 station<br>Won't save to Flash. |
| AT+CIPSTAMAC_DEF   | Set MAC address of ESP8266 station<br>Save to Flash.       |
| AT+CIPAPMAC        | Set MAC address of ESP8266 soft-AP<br>[@deprecated]        |
| AT+CIPAPMAC_CUR    | Set MAC address of ESP8266 soft-AP<br>Won't save to Flash. |
| AT+CIPAPMAC_DEF    | Set MAC address of ESP8266 soft-AP<br>Save to Flash.       |
| AT+CIPSTA          | Set IP address of ESP8266 station, [@deprecated]           |
| AT+CIPSTA_CUR      | Set IP address of ESP8266 station<br>Won't save to Flash.  |
| AT+CIPSTA_DEF      | Set IP address of ESP8266 station<br>Save to Flash.        |
| AT+CIPAP           | Set IP address of ESP8266 soft-AP, [@deprecated]           |
| AT+CIPAP_CUR       | Set IP address of ESP8266 soft-AP<br>Won't save to Flash.  |
| AT+CIPAP_DEF       | Set IP address of ESP8266 soft-AP<br>Save to Flash.        |
| AT+CWSTARTSMART    | Start SmartConfig  |
| AT+CWSTOPSMART     | Stop SmartConfig   |
| AT+CWSTARTDISCOVER | Start the mode that ESP8266 can be found by WeChat         |
| AT+CWSTOPDISCOVER  | Stop the mode that ESP8266 can be found by WeChat          |
| AT+WPS             | Set WPS function   |
| AT+MDNS            | Set MDNS function  |



## 4.1. Commands

### 1. AT+CWMODE – WiFi mode

The function of this AT command is to get the value scope of WiFi mode, including station mode, softAP mode, and station+softAP mode, enquiry about the information of WiFi mode, or set the WiFi mode.

| AT+CWMODE - WiFi mode  |  |
|--|--|
| This command is deprecated. Please use AT+CWMODE_CUR or AT+CWMODE_DEF instead. |  |
| <b>Command</b>   | <b>AT+CWMODE=?</b>   |
| <b>Response</b>  | +CWMODE:( value scope of <mode>)<br>OK   |
| <b>Parameters</b>  | Please refer to AT command settings.   |
| <b>Command</b>   | <b>AT+CWMODE?</b>  |
| <b>Response</b>  | +CWMODE:<mode><br>OK   |
| <b>Parameters</b>  | Please refer to AT command settings.   |
| <b>Command</b>   | <b>AT+CWMODE=&lt;mode&gt;</b>  |
| <b>Response</b>  | OK   |
| <b>Parameters</b>  | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode   |
| <b>Notes</b>   | This setting will be stored in the flash system parameter area. It won't be erased even when the power is off and restarted. |



## 2. AT+CWMODE\_CUR – current WiFi mode

There are three WiFi working modes: Station mode, softAP mode, and the co-existence of Station mode and softAP mode. This command is used to acquire the existing WiFi mode, or to set a customised WiFi mode.

| AT+CWMODE_CUR - Set WiFi mode (sta/AP/sta+AP) , won't save to Flash |  |
|---|--|
| Example   | AT+CWMODE_CUR=3  |
| Command   | AT+CWMODE_CUR=?  |
| Response  | +CWMODE_CUR:( value scope of <mode><br>OK                                  |
| Parameters  | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Command   | AT+CWMODE_CUR?   |
| Response  | +CWMODE_CUR:<mode><br>OK   |
| Parameters  | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Command   | AT+CWMODE_CUR=<mode>   |
| Response  | OK   |
| Parameters  | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Notes   | This configuration will <b>NOT</b> store in Flash.                         |



### 3. AT+CWMODE\_DEF – default WiFi mode

| AT+CWMODE_DEF - WiFi mode (sta/AP/sta+AP), save to Flash |  |
|--|--|
| Example  | AT+CWMODE_DEF=3  |
| Command  | AT+CWMODE_DEF=?  |
| Response   | +CWMODE_DEF:( value scope of <mode><br>OK                                  |
| Parameters   | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Command  | AT+CWMODE_DEF?   |
| Response   | +CWMODE_DEF:<mode><br>OK   |
| Parameters   | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Command  | AT+CWMODE_DEF=<mode>   |
| Response   | OK   |
| Parameters   | <mode><br>1 : station mode<br>2 : softAP mode<br>3 : softAP + station mode |
| Notes  | This configuration will store in Flash system parameter area.              |



#### 4. AT+CWJAP – Connect to AP

##### AT+CWJAP – Connect to AP

[@deprecated]. Please use AT+CWJAP\_CUR or AT+CWJAP\_DEF instead.

|                   |  |
|-------------------|--|
| <b>Example</b>    | <ul style="list-style-type: none"><li>• AT+CWJAP ="abc", "0123456789"</li><li>• If SSID is "ab/,c" and password is "0123456789"/"<br/>AT+CWJAP ="ab///,c", "0123456789///"</li><li>• If several APs have the same SSID as "abc", target AP can be found by bssid:<br/>AT+CWJAP ="abc","0123456789","ca:d7:19:d8:a6:44"</li></ul>   |
| <b>Command</b>    | <b>AT+CWJAP?</b>   |
| <b>Response</b>   | +CWJAP:<ssid>,<bssid>,<channel>,<rssi><br><br>OK   |
| <b>Parameters</b> | <ssid> string, AP's SSID   |
| <b>Command</b>    | <b>AT+CWJAP=&lt;ssid&gt;,&lt;pwd&gt;[,&lt;bssid&gt;]</b>   |
| <b>Response</b>   | OK<br><br>or<br><br>+CWJAP:<error code><br><br>FAIL  |
| <b>Parameters</b> | <ssid> string, AP's SSID<br><pwd> string, MAX: 64 bytes ASCII<br>[<bssid>] string, AP's MAC address, for several APs may have the same SSID<br><error code> only for reference, it's not reliable<br><error code> 1 connecting timeout<br><error code> 2 wrong password<br><error code> 3 can not found target AP<br><error code> 4 connect fail<br><br>This command needs station mode enable.<br>Escape character syntax is needed if "SSID" or "password" contains any special characters (''、 ""and'') |
| <b>Notes</b>      | This configuration will store in Flash system parameter area.  |



## 5. AT+CWJAP\_CUR – Connect to AP, for current

| AT+CWJAP_CUR - Connect to AP, won't save to Flash |  |
|---|--|
| <b>Example</b>                                    | <ul style="list-style-type: none"><li>• AT+CWJAP_CUR ="abc","0123456789"</li><li>• If SSID is "ab/,c" and password is "0123456789"/"<br/>AT+CWJAP_CUR="ab///,c","0123456789"//"</li><li>• If several APs have the same SSID as "abc",target AP can be found by bssid:<br/>AT+CWJAP_CUR="abc","0123456789","ca:d7:19:d8:a6:44"</li></ul>  |
| <b>Command</b>                                    | <b>AT+CWJAP_CUR?</b>   |
| <b>Response</b>                                   | +CWJAP_CUR:<ssid>,<bssid>,<channel>,<rssi><br><br>OK   |
| <b>Parameters</b>                                 | <ssid> string, AP's SSID   |
| <b>Command</b>                                    | <b>AT+CWJAP_CUR=&lt;ssid&gt;,&lt;pwd&gt;[,&lt;bssid&gt;]</b>   |
| <b>Response</b>                                   | OK<br><br>or<br><br>+CWJAP:<error code><br><br>FAIL  |
| <b>Parameters</b>                                 | <ssid> string, AP's SSID<br><pwd> string, MAX: 64 bytes ASCII<br>[<bssid>] string, AP's MAC address, for several APs may have the same SSID<br><error code> only for reference,it's not reliable<br><error code> 1 connecting timeout<br><error code> 2 wrong password<br><error code> 3 can not found target AP<br><error code> 4 connect fail<br><br>This command needs station mode enable.<br>Escape character syntax is needed if "SSID" or "password" contains any special characters('`、 `""and'`') |
| <b>Notes</b>                                      | This configuration will <b>NOT</b> store in Flash .  |



## 6. AT+CWJAP\_DEF – Connect to AP, save as default

| AT+CWJAP_DEF - Connect to AP and save AP info to flash |  |
|--|--|
| <b>Example</b>   | <ul style="list-style-type: none"><li>• AT+CWJAP_DEF="abc","0123456789"</li><li>• If SSID is "ab//c" and password is "0123456789"/"<br/>AT+CWJAP_DEF="ab///c","0123456789///"</li><li>• If several APs have the same SSID as "abc", target AP can be found by bssid:<br/>AT+CWJAP_DEF = "abc","0123456789","","ca:d7:19:d8:a6:44"</li></ul>  |
| <b>Command</b>   | <b>AT+CWJAP_DEF?</b>   |
| <b>Response</b>  | +CWJAP_DEF:<ssid>,<bssid>,<channel>,<rssi><br>OK   |
| <b>Parameters</b>                                      | <ssid> string, AP's SSID   |
| <b>Command</b>   | <b>AT+CWJAP_DEF=&lt;ssid&gt;,&lt;pwd&gt;[,&lt;bssid&gt;]</b>   |
| <b>Response</b>  | OK<br>or<br>+CWJAP:<error code><br><br>FAIL  |
| <b>Parameters</b>                                      | <ssid> string, AP's SSID<br><pwd> string, MAX: 64 bytes ASCII<br>[<bssid>] string, AP's bssid(MAC address), for several APs may have the same SSID<br><error code> only for reference, it's not reliable<br><error code> 1 connecting timeout<br><error code> 2 wrong password<br><error code> 3 can not found target AP<br><error code> 4 connect fail<br><br>This command needs station mode enable.<br>Escape character syntax is needed if "SSID" or "password" contains any special characters ('` `` "" and '/') |
| <b>Notes</b>   | This configuration will store in Flash system parameter area.  |



## 7. AT+CWLAPOPT – Set configuration for command AT+CWLAP

This command is to set the configuration for command AT+CWLAP, whether the result of AT+CWLAP will be ordered according to <rssi>, and which parameters will be shown in the result of AT+CWLAP.

| AT+CWLAPOPT - Set configuration for command AT+CWLAP |  |
|--|--|
| <b>Example</b>                                       | AT+CWLAPOPT=1,127<br>The first parameter is 1, means that the result of command AT+CWLAP will be listed according to <rssi><br>The second parameter 127 which is 0x7F, means that all bits in <mask> are 1, so all parameters in the result of AT+CWLAP will be shown.   |
| <b>Command</b>                                       | <b>AT+CWLAPOPT =&lt;sort_enable&gt;,&lt;mask&gt;</b>   |
| <b>Response</b>                                      | OK or ERROR  |
| <b>Parameters</b>                                    | <p>&lt;sort_enable&gt;<br/>whether the result of AT+CWLAP will be ordered according to &lt;rssi&gt;<br/>0 do not order by &lt;rssi&gt;<br/>1 order by &lt;rssi&gt;</p> <p>&lt;mask&gt;<br/>which parameters will be shown in the result of AT+CWLAP, 0 means that do not show the parameter corresponding to the bit, 1 means to show it.<br/>bit 0 sets whether &lt;ecn&gt; will be shown in the result of AT+CWLAP ,<br/>bit 1 sets whether &lt;ssid&gt; will be shown in the result of AT+CWLAP ,<br/>bit 2 sets whether &lt;rssi&gt; will be shown in the result of AT+CWLAP ,<br/>bit 3 sets whether &lt;mac&gt; will be shown in the result of AT+CWLAP ,<br/>bit 4 sets whether &lt;ch&gt; will be shown in the result of AT+CWLAP ,<br/>bit 5 sets whether &lt;freq offset&gt; will be shown in the result of AT+CWLAP ,<br/>bit 6 sets whether &lt;freq calibration&gt; will be shown in the result of AT+CWLAP .</p> |



## 8. AT+CWLAP – List available APs

| AT+CWLAP - Lists available APs |  |
|--------------------------------|--|
| <b>Example</b>                 | <ul style="list-style-type: none"><li>• AT+CWLAP<br/>List of all available AP's detected by ESP8266</li><li>• AT+CWLAP="WiFi","ca:d7:19:d8:a6:44",6<br/>Find AP with specific SSID and MAC at specific channel.</li><li>• AT+CWLAP="WiFi"<br/>Find AP with specific SSID</li></ul>   |
| <b>Command</b>                 | <b>AT+CWLAP=&lt;ssid&gt;[,&lt;mac&gt;,&lt;ch&gt;]</b>  |
| <b>Response</b>                | +CWLAP:<ecn>,<ssid>,<rssi>,<mac>,<ch>,<freq offset>,<freq calibration><br><br>OK<br>ERROR  |
| <b>Parameters</b>              | <ecn><br>0 OPEN<br>1 WEP<br>2 WPA_PSK<br>3 WPA2_PSK<br>4 WPA_WPA2_PSK<br><ssid> string, SSID of AP<br><rssi> signal strength<br><mac> string, MAC address<br><freq offset> frequency offset of AP , unit: KHz. The value of <freq offset> / 2.4 to get the value as ppm<br><freq calibration> calibration for frequency offset |
| <b>Command</b>                 | <b>AT+CWLAP</b>  |
| <b>Response</b>                | +CWLAP:<ecn>,<ssid>,<rssi>,<mac>,<ch>,<freq offset>,<freq calibration><br><br>OK<br>ERROR  |
| <b>Parameters</b>              | The same as above  |



## 9. AT+CWQAP – Disconnect from AP

| AT+CWQAP - Disconnect from AP |           |
|-------------------------------|-----------|
| Command                       | AT+ CWQAP |
| Response                      | OK        |
| Parameters                    | null      |

## 10. AT+CWSAP – Configuration of softAP mode

| AT+ CWSAP – Configuration of softAP mode                               |   |
|--|---|
| <b>[@deprecated]. Please use AT+CWSAP_CUR or AT+CWSAP_DEF instead.</b> |   |
| Example  | AT+CWSAP="ESP8266","1234567890",5,3   |
| Command  | AT+CWSAP?   |
| Response   | +CWSAP:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| Parameters   | <br><b>&lt;ssid&gt;</b> string, ESP8266 softAP' SSID<br><b>&lt;pwd&gt;</b> string, range: 8 ~ 64 bytes ASCII<br><b>&lt;chl&gt;</b> channel id<br><b>&lt;ecn&gt;</b><br>0 OPEN<br>2 WPA_PSK<br>3 WPA2_PSK<br>4 WPA_WPA2_PSK<br><b>&lt;max conn&gt;</b><br>maximum count of stations that allowed to connect to ESP8266 soft-AP<br>range: [1, 4]<br><b>&lt;ssid hidden&gt;</b> Broadcast SSID by default<br>0 broadcast SSID of ESP8266 soft-AP<br>1 do not broadcast SSID of ESP8266 soft-AP |
| Command  | AT+CWSAP=<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| Response   | OK<br>ERROR   |
| Parameters   | The same as above.  |
| Notes  | This CMD is only available when softAP mode enable.<br>ESP8266 softAP don't support WEP.<br>This configuration will store in Flash system parameter area.   |



## 11. AT+CWSAP\_CUR – Current config of softAP mode

| AT+CWSAP_CUR - Set configuration of softAP mode, won't save to Flash |   |
|--|---|
| <b>Example</b>   | AT+CWSAP_CUR="ESP8266","1234567890",5,3   |
| <b>Command</b>   | <b>AT+CWSAP_CUR?</b>  |
| <b>Response</b>  | +CWSAP_CUR:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| <b>Parameters</b>  | <p>&lt;ssid&gt; string, ESP8266 softAP' SSID<br/>&lt;pwd&gt; string, range: 8 ~ 64 bytes ASCII<br/>&lt;chl&gt; channel id<br/>&lt;ecn&gt;<br/>0 OPEN<br/>2 WPA_PSK<br/>3 WPA2_PSK<br/>4 WPA_WPA2_PSK<br/>&lt;max conn&gt;<br/>maximum count of stations that allowed to connect to ESP8266 soft-AP<br/>range: [1, 4]<br/>&lt;ssid hidden&gt; Broadcast SSID by default<br/>0 broadcast SSID of ESP8266 soft-AP<br/>1 do not broadcast SSID of ESP8266 soft-AP</p> |
| <b>Command</b>   | AT+CWSAP_CUR=<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| <b>Response</b>  | OK<br>ERROR   |
| <b>Parameters</b>  | The same as above.  |
| <b>Notes</b>   | This command is only available when softAP mode enable.<br>ESP8266 softAP don't support WEP.<br>This configuration will <b>NOT</b> store in Flash.  |



## 12. AT+CWSAP\_DEF – Default config of softAP mode

### AT+ CWSAP\_DEF - Set configuration of softAP mode, save to Flash

|                   |   |
|-------------------|---|
| <b>Example</b>    | AT+CWSAP_DEF="ESP8266","1234567890",5,3   |
| <b>Command</b>    | AT+CWSAP_DEF?   |
| <b>Response</b>   | +CWSAP_DEF:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| <b>Parameters</b> | <p>&lt;ssid&gt; string, ESP8266 softAP' SSID<br/>&lt;pwd&gt; string, range: 8 ~ 64 bytes ASCII<br/>&lt;chl&gt; channel ID<br/>&lt;ecn&gt;<br/>0 OPEN<br/>2 WPA_PSK<br/>3 WPA2_PSK<br/>4 WPA_WPA2_PSK<br/>&lt;max conn&gt;<br/>maximum count of stations that allowed to connect to ESP8266 soft-AP<br/>range: [1, 4]<br/>&lt;ssid hidden&gt; Broadcast SSID by default<br/>0 broadcast SSID of ESP8266 soft-AP<br/>1 do not broadcast SSID of ESP8266 soft-AP</p> |
| <b>Command</b>    | AT+CWSAP_DEF=<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden>  |
| <b>Response</b>   | OK<br>ERROR   |
| <b>Parameters</b> | The same as above.  |
| <b>Notes</b>      | This command is only available when softAP mode enable.<br>ESP8266 softAP don't support WEP.<br><b>This configuration will store in Flash system parameter area.</b>  |



### 13. AT+CWLIF – IP of stations

This command is used to get the IP of stations that are connected to ESP8266 softAP.

| AT+ CWLIF- IP of stations which are connected to ESP8266 softAP |   |
|---|---|
| <b>Response</b>   | <IP addr>,<mac><br>OK   |
| <b>Parameters</b>   | <IP addr> IP address of stations which are connected to ESP8266 softAP<br><mac> MAC address of stations which are connected to ESP8266 softAP |
| <b>Notes</b>  | This command can not get static IP , it is only available if DHCP is enabled.   |



## 14. AT+CWDHCP – Enable/Disable DHCP

| AT+ CWDHCP - Enable/Disable DHCP   |  |
|--|--|
| <b>[@deprecated]. Please use AT+CWDHCP_CUR or AT+CWDHCP_DEF instead.</b> |  |
| <b>Command</b>   | <b>AT+CWDHCP?</b>  |
| <b>Response</b>  | DHCP disabled or enabled now?  |
| <b>Parameters</b>  | Bit0 : 0 - soft-AP DHCP disable<br>1 - soft-AP DHCP enable<br>bit1 : 0 - station DHCP disable<br>1 - station DHCP enable   |
| <b>Command</b>   | <b>AT+CWDHCP=&lt;mode&gt;,&lt;en&gt;</b>   |
| <b>Response</b>  | OK   |
| <b>Parameters</b>  | <b>&lt;mode&gt;</b><br>0 : set ESP8266 soft-AP<br>1 : set ESP8266 station<br>2 : set both softAP and station<br><b>&lt;en&gt;</b><br>0 : Disable DHCP<br>1 : Enable DHCP   |
| <b>Notes</b>   | <ul style="list-style-type: none"><li>This configuration will store in Flash user parameter area.</li><li>This configuration interact with static IP related AT commands (<a href="#">AT+CIPSTA</a> related and <a href="#">AT+CIPAP</a> related):<ul style="list-style-type: none"><li>If enable DHCP, static IP will be disabled;</li><li>If enable static IP, DHCP will be disabled;</li><li>This will depends on the last configuration.</li></ul></li></ul> |



## 15. AT+CWDHCP\_CUR – Enable/Disable DHCP

| AT+ CWDHCP_CUR – Enable/Disable DHCP, won't save to flash |  |
|---|--|
| <b>Command</b>  | <b>AT+CWDHCP_CUR?</b>  |
| <b>Response</b>   | DHCP disabled or enabled now?  |
| <b>Parameters</b>   | Bit0 : 0 - soft-AP DHCP disable<br>1 - soft-AP DHCP enable<br>bit1 : 0 - station DHCP disable<br>1 - station DHCP enable   |
| <b>Command</b>  | <b>AT+CWDHCP_CUR=&lt;mode&gt;,&lt;en&gt;</b>   |
| <b>Response</b>   | OK   |
| <b>Parameters</b>   | <br><b>&lt;mode&gt;</b><br>0 : set ESP8266 soft-AP<br>1 : set ESP8266 station<br>2 : set both softAP and station<br><b>&lt;en&gt;</b><br>0 : Disable DHCP<br>1 : Enable DHCP   |
| <b>Notes</b>  | <ul style="list-style-type: none"><li>This configuration will <b>NOT</b> store in Flash user parameter area.</li><li>This configuration interact with static IP related AT commands (<a href="#">AT+CIPSTA</a> related and <a href="#">AT+CIPAP</a> related):<ul style="list-style-type: none"><li>If enable DHCP, static IP will be disabled;</li><li>If enable static IP, DHCP will be disabled;</li></ul></li></ul> |



## 16. AT+CWDHCP\_DEF – Enable/Disable DHCP and save to Flash

| AT+ CWDHCP_DEF - Enable/Disable DHCP and save to flash |  |
|--|--|
| Command  | AT+CWDHCP_DEF?   |
| Response   | DHCP disabled or enabled now?  |
| Parameters   | Bit0 : 0 - soft-AP DHCP disable<br>1 - soft-AP DHCP enable<br>bit1 : 0 - station DHCP disable<br>1 - station DHCP enable   |
| Command  | AT+CWDHCP_DEF=<mode>,<en>  |
| Response   | OK   |
| Parameters   | <mode><br>0 : set ESP8266 soft-AP<br>1 : set ESP8266 station<br>2 : set both softAP and station<br><en><br>0 : Disable DHCP<br>1 : Enable DHCP   |
| Notes  | <ul style="list-style-type: none"><li>This configuration will store in Flash user parameter area.</li><li>This configuration interact with static IP related AT commands (<a href="#">AT+CIPSTA</a> related and <a href="#">AT+CIPAP</a> related):<ul style="list-style-type: none"><li>If enable DHCP, static IP will be disabled;</li><li>If enable static IP, DHCP will be disabled;</li><li>This will depends on the last configuration.</li></ul></li></ul> |



### 17. AT+CWDHCPs\_CUR – Set the IP address allocated by ESP8266 soft-AP DHCP, cannot save to flash

This AT command is enabled when ESP8266 runs as soft-AP, and when DHCP server is running normally. The IP address should be on the same network segment with the IP address of ESP8266 soft-AP. This configuration will not be stored in Flash.

| AT+CWDHCPs_CUR - Set the IP address allocated by ESP8266 soft-AP DHCP, not be stored in flash |   |
|---|---|
| <b>Example</b>  | AT+CWDHCPs_CUR=1,3,"192.168.4.10","192.168.4.15"<br>or<br>AT+CWDHCPs_CUR=0 // Disable the settings and use the default IP range.  |
| <b>Command</b>  | <b>AT+CWDHCPs_CUR?</b>  |
| <b>Response</b>   | +CWDHCPs_CUR=<lease time>,<start IP>,<end IP>   |
| <b>Parameters</b>   | <enable> 0 : Disable the settings and use the default IP range.<br>1: Enable setting the IP range, parameters below have to be set.<br><lease time> the unit of lease time is minute, range [1, 2880]<br><start IP> start IP of the IP range that can be got from ESP8266 soft-AP DHCP server<br><end IP> end IP of the IP range that can be got from ESP8266 soft-AP DHCP server |
| <b>Command</b>  | <b>AT+CWDHCPs_CUR=&lt;enable&gt;,&lt;lease time&gt;,&lt;start IP&gt;,&lt;end IP&gt;</b>   |
| <b>Response</b>   | OK  |
| <b>Parameters</b>   | The same as above.  |

**18. AT+CWDHCPs\_DEF – Set the IP address allocated by ESP8266 soft-AP DHCP, save to flash**

This AT command is enabled when ESP8266 runs as soft-AP, and when DHCP server is running normally. The IP address should be on the same network segment with the IP address of ESP8266 soft-AP. This configuration will be stored in Flash user parameter area.

| AT+CWDHCPs_DEF - Set the IP address allocated by ESP8266 soft-AP DHCP, can be stored in flash |   |
|---|---|
| <b>Example</b>  | AT+CWDHCPs_DEF=1,3,"192.168.4.10","192.168.4.15"<br>or<br>AT+CWDHCPs_DEF=0 // Disable the settings and use the default IP range.  |
| <b>Command</b>  | <b>AT+CWDHCPs_DEF?</b>  |
| <b>Response</b>   | +CWDHCPs_DEF=<lease time>,<start IP>,<end IP>   |
| <b>Parameters</b>   | <enable> 0 : Disable the settings and use the default IP range.<br>1: Enable setting the IP range, parameters below have to be set.<br><lease time> the unit of lease time is minute, range [1, 2880]<br><start IP> start IP of the IP range that can be got from ESP8266 soft-AP DHCP server<br><end IP> end IP of the IP range that can be got from ESP8266 soft-AP DHCP server |
| <b>Command</b>  | <b>AT+CWDHCPs_DEF=&lt;enable&gt;,&lt;lease time&gt;,&lt;start IP&gt;,&lt;end IP&gt;</b>   |
| <b>Response</b>   | OK  |
| <b>Parameters</b>   | The same as above.  |

**19. AT+CWAUTOCONN – Auto connect to AP or not**

ESP8266 station will connect to AP automatically when power on by default.

| AT+CWAUTOCONN - Connect to AP automatically or not |  |
|--|--|
| <b>Example</b>                                     | AT+CWAUTOCONN=1  |
| <b>Command</b>                                     | <b>AT+CWAUTOCONN=&lt;enable&gt;</b>  |
| <b>Response</b>                                    | OK   |
| <b>Parameters</b>                                  | <enable><br>0 : do NOT auto-connect to AP when power on<br>1 : connect to AP automatically when power on |
| <b>Notes</b>                                       | This configuration will store in Flash system parameter area.  |



## 20. AT+CIPSTAMAC – Set MAC address of station

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "18:fe:35:98:d3:7b", but can not be "18:fe:35:98:d3:7b".

| AT+ CIPSTAMAC - Set MAC address of ESP8266 station                      |   |
|---|---|
| <b>[@deprecated]. Use AT+CIPSTAMAC_CUR or AT+CIPSTAMAC_DEF instead.</b> |   |
| <b>Example</b>  | AT+CIPSTAMAC="18:fe:35:98:d3:7b"                            |
| <b>Command</b>  | <b>AT+CIPSTAMAC?</b>  |
| <b>Response</b>   | +CIPSTAMAC:<mac><br>OK                                      |
| <b>Parameters</b>   | <mac> string, MAC address of ESP8266 station                |
| <b>Command</b>  | <b>AT+CIPSTAMAC=&lt;mac&gt;</b>                             |
| <b>Response</b>   | OK  |
| <b>Parameters</b>   | <mac> string, MAC address of ESP8266 station                |
| <b>Notes</b>  | This configuration will store in Flash user parameter area. |



## 21. AT+CIPSTAMAC\_CUR – Set MAC address of station

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "18:fe:35:98:d3:7b", but can not be "18:fe:35:98:d3:7b".

| AT+ CIPSTAMAC_CUR - Set MAC address of ESP8266 station, won't save to Flash |  |
|---|--|
| Example   | AT+CIPSTAMAC_CUR="18:fe:35:98:d3:7b"               |
| Command   | AT+CIPSTAMAC_CUR?                                  |
| Response  | +CIPSTAMAC_CUR:<mac><br>OK                         |
| Parameters  | <mac> string, MAC address of ESP8266 station       |
| Command   | AT+CIPSTAMAC_CUR=<mac>                             |
| Response  | OK   |
| Parameters  | <mac> string, MAC address of ESP8266 station       |
| Notes   | This configuration will <b>NOT</b> store in Flash. |

## 22. AT+CIPSTAMAC\_DEF – Set MAC address of station, save as default

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "18:fe:35:98:d3:7b", but can not be "18:fe:35:98:d3:7b".

| AT+ CIPSTAMAC_DEF - Set MAC address of ESP8266 station, save to Flash |   |
|---|---|
| Example   | AT+CIPSTAMAC_DEF="18:fe:35:98:d3:7b"                        |
| Command   | AT+CIPSTAMAC_DEF?   |
| Response  | +CIPSTAMAC_DEF:<mac><br>OK                                  |
| Parameters  | <mac> string, MAC address of ESP8266 station                |
| Command   | AT+CIPSTAMAC_DEF=<mac>                                      |
| Response  | OK  |
| Parameters  | <mac> string, MAC address of ESP8266 station                |
| Notes   | This configuration will store in Flash user parameter area. |



### 23. AT+CIPAPMAC – Set MAC address of softAP

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "1a:fe:36:97:d5:7b", but can not be "15:fe:36:97:d5:7b".

| AT+ CIPAPMAC - Set MAC address of ESP8266 softAP                      |   |
|---|---|
| <b>[@deprecated]. Use AT+CIPAPMAC_CUR or AT+CIPAPMAC_DEF instead.</b> |   |
| Example   | AT+CIPAPMAC="1a:fe:36:97:d5:7b"                             |
| Command   | <b>AT+CIPAPMAC?</b>   |
| Response  | +CIPAPMAC:<mac><br>OK                                       |
| Parameters  | <mac> string, MAC address of ESP8266 softAP                 |
| Command   | <b>AT+CIPAPMAC=&lt;mac&gt;</b>                              |
| Response  | OK  |
| Parameters  | <mac> string, MAC address of ESP8266 softAP                 |
| Notes   | This configuration will store in Flash user parameter area. |

### 24. AT+CIPAPMAC\_CUR – Set MAC address of softAP

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "1a:fe:36:97:d5:7b", but can not be "15:fe:36:97:d5:7b".

| AT+CIPAPMAC_CUR - Set MAC addr of ESP8266 softAP, won't save to Flash |  |
|---|--|
| Example   | AT+CIPAPMAC_CUR="1a:fe:36:97:d5:7b"                |
| Command   | <b>AT+CIPAPMAC_CUR?</b>                            |
| Response  | +CIPAPMAC_CUR:<mac><br>OK                          |
| Parameters  | <mac> string, MAC address of ESP8266 soft-AP       |
| Command   | <b>AT+CIPAPMAC_CUR=&lt;mac&gt;</b>                 |
| Response  | OK   |
| Parameters  | <mac> string, MAC address of ESP8266 soft-AP       |
| Notes   | This configuration will <b>not</b> store in Flash. |



## 25. AT+CIPAPMAC\_DEF – Set MAC address of softAP and save as default

MAC addresses of ESP8266 soft-AP and station are different, please do **NOT** set them to be the same. And the bit 0 of the first byte of ESP8266 MAC address can not be 1, for example, MAC address can be "1a:fe:36:97:d5:7b", but can not be "15:fe:36:97:d5:7b".

| AT+ CIPAPMAC_DEF – Set MAC address of ESP8266 softAP, save to Flash |   |
|---|---|
| <b>Example</b>  | AT+CIPAPMAC_DEF="1a:fe:36:97:d5:7b"                         |
| <b>Command</b>  | <b>AT+CIPAPMAC_DEF?</b>                                     |
| <b>Response</b>   | +CIPAPMAC_DEF:<mac><br>OK                                   |
| <b>Parameters</b>   | <mac> string, MAC address of ESP8266 soft-AP                |
| <b>Command</b>  | <b>AT+CIPAPMAC_DEF=&lt;mac&gt;</b>                          |
| <b>Response</b>   | OK  |
| <b>Parameters</b>   | <mac> string, MAC address of ESP8266 soft-AP                |
| <b>Notes</b>  | This configuration will store in Flash user parameter area. |



## 26. AT+CIPSTA – Set IP address of station

Only after ESP8266 station connected to AP, station IP can be got and inquired. This configuration will store in Flash user parameter area.

| AT+ CIPSTA - Set IP address of ESP8266 station                           |  |
|--|--|
| <b>[@deprecated]. Please use AT+CIPSTA_CUR or AT+CIPSTA_DEF instead.</b> |  |
| <b>Example</b>   | AT+CIPSTA="192.168.6.100","192.168.6.1","255.255.255.0"  |
| <b>Command</b>   | <b>AT+CIPSTA?</b>  |
| <b>Response</b>  | +CIPSTA:<IP><br><br>OK   |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 station   |
| <b>Command</b>   | <b>AT+CIPSTA=&lt;IP&gt;[,&lt;gateway&gt;,&lt;netmask&gt;]</b>  |
| <b>Response</b>  | OK   |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 station<br>[<gateway>] gateway<br>[<netmask>] netmask   |
| <b>Notes</b>   | This configuration interacts with <a href="#">AT+CWDHCP</a> related AT commands: <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |



## 27. AT+CIPSTA\_CUR – Set IP address of station

Only after ESP8266 station connected to AP, station IP can be got and inquired. This configuration will **NOT** store in Flash.

| AT+CIPSTA_CUR - Set IP address of ESP8266 station, won't save to Flash |  |
|--|--|
| <b>Example</b>   | AT+CIPSTA_CUR="192.168.6.100","192.168.6.1","255.255.255.0"  |
| <b>Command</b>   | <b>AT+CIPSTA_CUR?</b>  |
| <b>Response</b>  | +CIPSTA_CUR:<IP><br>OK   |
| <b>Parameters</b>  | Param description<br><IP> string, IP address of ESP8266 station  |
| <b>Command</b>   | <b>AT+CIPSTA_CUR=&lt;IP&gt;[,&lt;gateway&gt;,&lt;netmask&gt;]</b>  |
| <b>Response</b>  | OK   |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 station<br>[<gateway>] gateway<br>[<netmask>] netmask   |
| <b>Notes</b>   | This configuration interacts with DHCP related AT commands ( <a href="#">AT+CWDHCP</a> related): <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |

**28. AT+CIPSTA\_DEF – Set IP address of station and save as default**

| AT+CIPSTA_DEF - Set IP address of ESP8266 station, save to Flash |   |
|--|---|
| <b>Example</b>   | AT+CIPSTA_DEF="192.168.6.100","192.168.6.1","255.255.255.0"   |
| <b>Command</b>   | <b>AT+CIPSTA_DEF?</b>   |
| <b>Response</b>  | +CIPSTA:<IP><br>OK  |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 station  |
| <b>Command</b>   | <b>AT+CIPSTA_DEF=&lt;IP&gt;[,&lt;gateway&gt;,&lt;netmask&gt;]</b>   |
| <b>Response</b>  | OK  |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 station<br>[<gateway>] gateway<br>[<netmask>] netmask  |
| <b>Notes</b>   | This configuration will store in Flash user parameter area.<br>This configuration interacts with DHCP related AT commands ( <a href="#">AT+CWDHCP</a> related): <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |



## 29. AT+CIPAP – Set IP address of softAP

ESP8266 only support class C IP address. This configuration will store in Flash user parameter area.

| AT+CIPAP – Set IP address of ESP8266 softAP                            |  |
|--|--|
| <b>[@deprecated]. Please use AT+CIPAP_CUR or AT+CIPAP_DEF instead.</b> |  |
| <b>Example</b>   | AT+CIPAP="192.168.5.1","192.168.5.1","255.255.255.0"   |
| <b>Command</b>   | <b>AT+CIPAP?</b>   |
| <b>Response</b>  | +CIPAP:<IP><br>OK  |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 softAP  |
| <b>Command</b>   | <b>AT+CIPAP=&lt;IP&gt;[,&lt;gateway&gt;,&lt;netmask&gt;]</b>   |
| <b>Response</b>  | OK   |
| <b>Parameters</b>  | <IP> string, IP address of ESP8266 softAP<br>[<gateway>] gateway<br>[<netmask>] netmask  |
| <b>Notes</b>   | This configuration interacts with DHCP related AT commands ( <a href="#">AT+CWDHCP</a> related): <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |



### 30. AT+CIPAP\_CUR – Set IP address of softAP

ESP8266 only support class C IP address. This configuration will **NOT** store in Flash.

| AT+CIPAP_CUR - Set IP address of ESP8266 softAP, won't save to Flash |  |
|--|--|
| Example  | AT+CIPAP_CUR="192.168.5.1","192.168.5.1","255.255.255.0"   |
| Command  | AT+CIPAP_CUR?  |
| Response   | +CIPAP_CUR:<IP><br>OK  |
| Parameters   | <IP> string, IP address of ESP8266 softAP  |
| Command  | AT+CIPAP_CUR=<IP>[,<gateway>,<netmask>]  |
| Response   | OK   |
| Parameters   | <IP> string, IP address of ESP8266 softAP<br>[<gateway>] gateway<br>[<netmask>] netmask  |
| Notes  | This configuration interacts with DHCP related AT commands ( <a href="#">AT+CWDHCP</a> related): <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |



### 31. AT+CIPAP\_DEF – Set IP address of softAP, save as default

ESP8266 only support class C IP address.

| AT+ CIPAP_DEF - Set IP address of ESP8266 softAP, save to Flash |   |
|---|---|
| Example   | AT+CIPAP_DEF="192.168.5.1","192.168.5.1","255.255.255.0"  |
| Command   | AT+CIPAP_DEF?   |
| Response  | +CIPAP_DEF:<IP><br>OK   |
| Parameters  | <IP> string, IP address of ESP8266 softAP   |
| Command   | AT+CIPAP_DEF=<IP>[,<gateway>,<netmask>]   |
| Response  | OK  |
| Parameters  | <IP> string, IP address of ESP8266 softAP<br>[<gateway>] gateway<br>[<netmask>] netmask   |
| Notes   | This configuration will store in Flash user parameter area.<br>This configuration interacts with DHCP related AT commands ( <a href="#">AT+CWDHCP</a> related): <ul style="list-style-type: none"><li>• If enable static IP, DHCP will be disabled;</li><li>• If enable DHCP, static IP will be disabled;</li><li>• This will depend on the last configuration.</li></ul> |



### 32. AT+CWSTARTSMART – Start SmartConfig

SmartConfig is only available in station mode. SmartConfig can get protocol type (AirKiss or ESP-TOUCH) automatically by command "AT+CWSTARTSMART". Or users can use command "AT+CWSTARTSMART=<type>" to set a specific protocol type.

| AT+CWSTARTSMART - Start SmartConfig |   |
|-------------------------------------|---|
| <b>Example</b>                      | AT+CWMODE=1<br>AT+CWSTARTSMART  |
| <b>Command</b>                      | <b>AT+CWSTARTSMART</b>  |
| <b>Response</b>                     | OK or ERROR   |
| <b>Parameters</b>                   | none  |
| <b>Notes</b>                        | The type of SmartConfig will be ESP-Touch + AirKiss, if the command is "AT+CWSTARTSMART"  |
| <b>Command</b>                      | <b>AT+CWSTARTSMART=&lt;type&gt;</b>   |
| <b>Response</b>                     | OK or ERROR   |
| <b>Parameters</b>                   | <type><br>1 : ESP-Touch<br>2 : AirKiss<br>3 : ESP-Touch + AirKiss   |
| <b>Notes</b>                        | <ul style="list-style-type: none"><li>Message "<a href="#">Smart get WiFi info</a>" means Smart Config get AP's information successfully, then ESP8266 try to connect to target AP, print "<a href="#">WiFi CONNECTED</a>" and "<a href="#">WiFi GOT IP</a>" if succeed;</li><li>ESP8266 can't do anything during SmartConfig so please wait till it succeed or use command "<a href="#">AT+CWSTOPSMART</a>" to stop SmartConfig.</li></ul> |

### 33. AT+CWSTOPSMART – stop SmartConfig

| AT+CWSTOPSMART stop SmartConfig |   |
|---------------------------------|---|
| <b>Command</b>                  | <b>AT+CWSTOPSMART</b>   |
| <b>Response</b>                 | OK or ERROR   |
| <b>Notes</b>                    | No matter SmartConfig succeed or not, before any other AT commands please always call "AT+CWSTOPSMART" to release the buffer it took first. |



### 34. AT+CWSTARTDISCOVER – Start the mode that ESP8266 can be found by WeChat

The parameter of this command needs to be got from Espressif Cloud. After connected to an AP and got an IP address, ESP8266 can be found by WeChat which is in the same LAN.

WeChat : <http://iot.weixin.qq.com>

| AT+CWSTARTDISCOVER  |  |
|---|--|
| - Start the mode that ESP8266 can be found by WeChat which is in the same LAN |  |
| Example   | AT+CWSTARTDISCOVER="gh_sdfe235xfs7k","122475",10   |
| Command   | AT+CWSTARTDISCOVER=<WeChat number>,<dev_type>, <time>  |
| Response  | OK or ERROR  |
| Parameters  | <WeChat number> got from WeChat<br><dev_type> got from WeChat<br><time><br>time interval that ESP8266 sends packet, range: 0 ~ 24x3600, unit : second.<br>0 : ESP8266 will not send packet, waiting for WeChat's detection.<br>Otherwise, it is the time interval that ESP8266 sends packet, so the WeChat may find it easier. |
| Notes   | ESP8266 station need to connect to an AP and get an IP address first. Then use this command so that WeChat can find this ESP8266 device.   |

### 35. AT+CWSTOPDISCOVER – Stop the mode that ESP8266 can be found by WeChat

| AT+CWSTOPDISCOVER  |                   |
|--|-------------------|
| - Stop the mode that ESP8266 can be found by WeChat which is in the same LAN |                   |
| Command  | AT+CWSTOPDISCOVER |
| Response   | OK or ERROR       |



### 36. AT+WPS – Set WPS function

Notice that WPS function can only be used when ESP8266 station is enabled. And WPS function does not support WEP encryption.

| AT+WPS - Set WPS function |   |
|---------------------------|---|
| Example                   | AT+CWMODE=1<br>AT+WPS=1                                     |
| Command                   | <b>AT+WPS=&lt;enable&gt;</b>                                |
| Response                  | OK or ERROR   |
| Parameter                 | <enable><br>1 : start WPS function<br>0 : stop WPS function |

### 37. AT+MDNS – Set MDNS function

Do not contain special characters (for example, “.” character), or use a protocol name (for example, “http”), when defining “host\_name” and “server\_name” for MDNS.

| AT+MDNS - Set MDNS function |  |
|-----------------------------|--|
| Example                     | AT+MDNS=1,"espressif","iot",8080   |
| Command                     | <b>AT+MDNS=&lt;enable&gt;, &lt;hostname&gt;, &lt;server_name&gt;, &lt;server_port&gt;</b>  |
| Response                    | OK or ERROR  |
| Parameter                   | <enable><br>1 : enable MDNS function<br>0 : disable MDNS function<br><hostname> MDNS host name<br><server_name> MDNS server name<br><server_port> MDNS server port |



## 5. TCP/IP Related AT Commands

### 5.1. Overview

| TCP/IP           |  |
|------------------|--|
| Command          | Description  |
| AT+ CIPSTATUS    | Get connection status  |
| AT+CIPSTART      | Establish TCP connection, UDP transmission or SSL connection |
| AT+CIPSSIZE      | Set the size of SSL buffer                                   |
| AT+CIPSEND       | Send data  |
| AT+CIPSENDEX     | Send data, if <length> or "\0" is met, data will be sent     |
| AT+CIPSENDDBUF   | Write data into TCP-send-buffer                              |
| AT+CIPBUFRST     | Reset segment ID count                                       |
| AT+CIPBUFSTATUS  | Check status of TCP-send-buffer                              |
| AT+CIPCHECKSEQ   | Check if a specific segment is sent or not                   |
| AT+CIPCLOSE      | Close TCP/UDP/SSL connection                                 |
| AT+CIFSR         | Get local IP address   |
| AT+CIPMUX        | Set multiple connections mode                                |
| AT+CIPSERVER     | Configure as server  |
| AT+CIPMODE       | Set transmission mode  |
| AT+SAVETRANSLINK | Save transparent transmission link to Flash                  |
| AT+CIPSTO        | Set timeout when ESP8266 runs as TCP server                  |
| AT+CIUPDATE      | Upgrade firmware through network                             |
| AT+PING          | Function PING  |
| AT+CIPDINFO      | Show remote IP and remote port with "+IPD"                   |



## 5.2. TCP/IP

### 1. AT+CIPSTATUS – Check network connection status

| AT+CIPSTATUS - Check network connection status |  |
|--|--|
| Command  | AT+CIPSTATUS   |
| Response                                       | STATUS:<stat><br>+CIPSTATUS:<link ID>,<type>,<remote_IP>,<remote_port>,<local_port>,<tetype>   |
| Parameters                                     | <stat><br>2 : Got IP<br>3 : Connected<br>4 : Disconnected<br>5 : Wi-Fi connection fail<br><link ID> ID of the connection (0~4), for multi-connect<br><type> string, "TCP" or "UDP"<br><remote_IP> string, remote IP address.<br><remote_port> remote port number<br><local_port> ESP8266 local port number<br><tetype><br>0: ESP8266 runs as client<br>1: ESP8266 runs as server |

### 2. AT+CIPSTART – Establish TCP connection, UDP transmission or SSL connection

Refer to documentation "4B-ESP8266\_AT Command Examples" on how to use this command.

| AT+CIPSTART - Function 1: Establish TCP connection |   |
|--|---|
| Example  | AT+CIPSTART="TCP","iot.espressif.cn",8000<br>AT+CIPSTART="TCP","192.168.101.110",1000 |
| Single connection<br>(AT+CIPMUX=0)                 | AT+CIPSTART=<br><type>,<remote IP>,<remote port>[,<TCP keep alive>]                   |
| Multiple connection<br>(AT+CIPMUX=1)               | AT+CIPSTART=<link ID> ,<br><type>,<remote IP>,<remote port>[,<TCP keep alive>]        |



|                   |   |
|-------------------|---|
| <b>Response</b>   | OK or ERROR<br>If TCP is connected already, returns<br>ALREADY CONNECT  |
| <b>Parameters</b> | <link ID> ID of network connection (0~4), used for multi-connection<br><type> string, "TCP" or "UDP"<br><remote IP> string, remote IP address<br><remote port> string, remote port number<br>[<TCP keep alive>] detection time interval when TCP is kept alive, this function is closed by default.<br>[<TCP keep alive>] 0 : disable TCP keep-alive<br>[<TCP keep alive>] 1 ~ 7200 : detection time interval, unit: second |

| AT+CIPSTART - Function 2: Register UDP port, start connection |   |
|---|---|
| <b>Example</b>  | AT+CIPSTART="UDP","192.168.101.110",1000,1002,2   |
| <b>Single connection</b><br>(AT+CIPMUX=0)                     | AT+CIPSTART=<type>,<remote IP>,<remote port>[,<UDP local port>,<UDP mode>]  |
| <b>Multiple connection</b><br>(AT+CIPMUX=1)                   | AT+CIPSTART=<link ID>,<type>,<remote IP>,<remote port>[,<UDP local port>,<UDP mode>]  |
| <b>Response</b>   | OK or ERROR<br>If connection already exists, returns<br>ALREADY CONNECT   |
| <b>Parameters</b>   | <link ID> ID of network connection (0~4), used for multi-connection<br><type> string, "TCP" or "UDP"<br><remote IP> string, remote IP<br><remote port> string, remote port<br>[<UDP local port>] UDP port of ESP8266<br>[<UDP mode>] In UDP transparent transmission, it has to be 0.<br>[<UDP mode>] 0 : destination peer entity of UDP will not change.<br>[<UDP mode>] 1 : destination peer entity of UDP can change once.<br>[<UDP mode>] 2 : destination peer entity of UDP is allowed to change.<br><br>Note: [<UDP mode>] can only be used when [<UDP local port>] is set. |



| AT+CIPSTART - Function 3: Establish SSL connection |  |
|--|--|
| <b>Example</b>                                     | AT+CIPSSLSIZE=4096<br>AT+CIPSTART="SSL","iot.espressif.cn",8443  |
| <b>Single connection</b><br>(AT+CIPMUX=0)          | <b>AT+CIPSTART=</b><br><b>&lt;type&gt;,&lt;remote IP&gt;,&lt;remote port&gt;[,&lt;TCP keep alive&gt;]</b>  |
| <b>Multiple connection</b><br>(AT+CIPMUX=1)        | <b>AT+CIPSTART=&lt;link ID&gt; ,</b><br><b>&lt;type&gt;,&lt;remote IP&gt;,&lt;remote port&gt;[,&lt;TCP keep alive&gt;]</b>   |
| <b>Response</b>                                    | OK or ERROR<br>If TCP is connected already, returns<br>ALREADY CONNECT   |
| <b>Parameters</b>                                  | <p><b>&lt;link ID&gt;</b> ID of network connection (0~4), used for multi-connection</p> <p><b>&lt;type&gt;</b> string, "SSL"</p> <p><b>&lt;remote IP&gt;</b> string, remote IP address</p> <p><b>&lt;remote port&gt;</b> string, remote port number</p> <p>[<b>&lt;TCP keep alive&gt;</b>] detection time interval when TCP is kept alive, this function is closed by default.</p> <p>[<b>&lt;TCP keep alive&gt;</b>] 0 : disable TCP keep-alive</p> <p>[<b>&lt;TCP keep alive&gt;</b>] 1 ~ 7200 : detection time interval, unit: second</p> |
| <b>Note</b>  | <ol style="list-style-type: none"> <li>1. ESP8266 can only set one SSL connection at most.</li> <li>2. SSL connection does not support UART-WiFi passthrough mode (transparent transmission).</li> <li>3. SSL connection needs a lot of memory, otherwise, it may cause system reboot. Users can try command "<b>AT+CIPSSLSIZE=&lt;size&gt;</b>" to enlarge the buffer size.</li> </ol>  |

### 3. AT+CIPSSLSIZE – Set the size of SSL buffer

| AT+CIPSSLSIZE - Set the size of SSL buffer |  |
|--|--|
| <b>Command</b>                             | <b>AT+CIPSSLSIZE=&lt;size&gt;</b>                              |
| <b>Response</b>                            | OK or ERROR  |
| <b>Parameters</b>                          | <b>&lt;size&gt;</b> the size of SSL buffer, range: 2048 ~ 4096 |



#### 4. AT+CIPSEND – Send data

Please refer to documentation "4B-ESP8266\_AT Command Examples" for more examples.

| AT+CIPSEND - Send data     |  |
|----------------------------|--|
| <b>Single connection</b>   | (+CIPMUX=0)<br><b>AT+CIPSEND=&lt;length&gt;</b>  |
| <b>Multiple connection</b> | (+CIPMUX=1)<br><b>AT+CIPSEND=&lt;link ID&gt;,&lt;length&gt;</b>  |
| <b>UDP Transmission</b>    | <b>AT+CIPSEND=[&lt;link ID&gt;,&lt;length&gt;[,&lt;remote IP&gt;,&lt;remote port&gt;]</b>  |
| <b>Response</b>            | Wrap return ">" after set command. Begins receive of serial data, when data length is met, starts transmission of data.<br><br>If connection cannot be established or gets disconnected during send, returns<br>ERROR<br>If data is transmitted successfully, returns<br>SEND OK   |
| <b>Parameters</b>          | <link ID> ID of the connection (0~4), for multi-connect<br><length> data length, MAX 2048 bytes<br>[<remote IP>] UDP transmission can set remote IP when send data<br>[<remote port>] UDP transmission can set remote port when send data  |
| <b>Command</b>             | <b>AT+CIPSEND</b>  |
| <b>Response</b>            | Wrap return ">" after execute command. Enters unvarnished transmission, 20ms interval between each packet, maximum 2048 bytes per packet. When single packet containing "+++" is received, it returns to normal command mode. Please wait at least 1 second before sending next AT command.<br><br>This command can only be used in transparent transmission mode which require to be single connection mode.<br>For UDP transparent transmission, <UDP mode> has to be 0 in command "AT+CIPSTART" |



## 5. AT+CIPSENDEX – Send data

| AT+CIPSENDEX - Send data |   |
|--------------------------|---|
| Single connection        | (+CIPMUX=0)<br><b>AT+CIPSENDEX=&lt;length&gt;</b>   |
| Multiple connection      | (+CIPMUX=1)<br><b>AT+CIPSENDEX=&lt;link ID&gt;,&lt;length&gt;</b>   |
| UDP Transmission         | <b>AT+CIPSENDEX=[&lt;link ID&gt;,]&lt;length&gt;[,&lt;remote IP&gt;,&lt;remote port&gt;]</b>  |
| Response                 | Wrap return ">" after set command. Begins receive of serial data, when data length or "\0" is met, starts transmission of data.<br>So if sending "\0" is needed, please send it as "\\0"<br><br>If connection cannot be established or gets disconnected during send, returns<br>ERROR<br>If data is transmitted successfully, returns<br>SEND OK |
| Parameters               | <b>&lt;link ID&gt;</b> ID of the connection (0~4), for multi-connect<br><b>&lt;length&gt;</b> data length, MAX 2048 bytes   |



## 6. AT+CIPSENDBUF – Write data into TCP-send-buffer

This command only write data into TCP-send-buffer, so it can be called continually, needn't wait for "SEND OK"; if a TCP segment is sent successfully, it will return <segment ID>,SEND OK. Before data <length> is met, input "+++" can switch back from data mode to command mode, and discard the data received before, cancel the "AT+CIPSENDBUF".

| AT+CIPSENDBUF - Write data into TCP-send-buffer |   |
|---|---|
| Single connection                               | (+CIPMUX=0)<br><b>AT+CIPSENDBUF=&lt;length&gt;</b>  |
| Multiple connection                             | (+CIPMUX=1)<br><b>AT+CIPSENDBUF=&lt;link ID&gt;,&lt;length&gt;</b>  |
| Response  | <current segment ID>,<segment ID of which sent successfully><br>OK<br>><br><br>Wrap return ">" begins receiving of serial data, when data <length> is met, send it; data more than <length> will be discarded, and returns "busy"<br><br>If connection cannot be established, or it's not a TCP connection , or buffer full, or some other error occurred, returns<br>ERROR<br><br>If data is transmitted successfully,<br>(1) for single connection, returns<br><segment ID>,SEND OK<br><br>(2) for multiple connection, returns<br><link ID>,<segment ID>,SEND OK |
| Parameters                                      | <link ID> ID of the connection (0~4), for multi-connect<br><segment ID> uint32, starts from 1, add 1 every time be called;<br><length> data length, data more than <length> will be discarded, MAX 2048 bytes   |



## 7. AT+CIPBUFSTATUS – Check status of TCP-send-buffer

Please do not user this command on SSL connection.

| AT+CIPBUFSTATUS - Check status of TCP-send-buffer |   |
|---|---|
| <b>Example</b>                                    | Single connection:<br><b>AT+CIPBUFSTATUS</b> returns <b>20,15,10,200,7</b><br><b>20</b> : means the latest segment ID is 19, next time we call <b>AT+CIPSEND</b> , the segment ID returned will be 20;<br><b>15</b> : means TCP segment of which ID is 15 is the latest segment that sent (may not succeed) ;<br><b>10</b> : means TCP segment of which ID is 10 sent successfully;<br><b>200</b> : TCP-send-buffer remain 200 bytes that available;<br><b>7</b> : available TCP queue number, it's not reliable; when queue number is 0, no more TCP data can be sent.   |
| <b>Single connection</b>                          | (+CIPMUX=0)<br><b>AT+CIPBUFSTATUS</b>   |
| <b>Multiple connection</b>                        | (+CIPMUX=1)<br><b>AT+CIPBUFSTATUS=&lt;link ID&gt;</b>   |
| <b>Response</b>                                   | <next segment ID>, <segment ID of which has sent>, <segment ID of which sent successfully>, <remain buffer size>, <queue number><br><br>OK<br><br>If connection is not established, returns<br>ERROR  |
| <b>Parameters</b>                                 | <b>&lt;link ID&gt;</b> ID of the connection (0~4), for multi-connect<br><b>&lt;next segment ID&gt;</b> next segment ID will be got by <b>AT+CIPSEND</b> ;<br><b>&lt;segment ID of which has sent&gt;</b> the latest segment that sent (may not succeed) ;<br><b>&lt;segment ID of which sent successfully&gt;</b> the latest segment that sent successfully;<br><b>&lt;remain buffer size&gt;</b> TCP-send-buffer remain buffer size;<br><b>&lt;queue number&gt;</b> available TCP queue number, it's not reliable; when queue number is 0, no more TCP data can be sent. |



## 8. AT+CIPCHECKSEQ – Check if specific segment sent successfully or not

| AT+CIPCHECKSEQ - Check if specific segment sent successfully or not |   |
|---|---|
| Single connection   | (+CIPMUX=0)<br><b>AT+CIPCHECKSEQ=&lt;segment ID&gt;</b>   |
| Multiple connection   | (+CIPMUX=1)<br><b>AT+CIPCHECKSEQ=&lt;link ID&gt;,&lt;segment ID&gt;</b>   |
| Response  | [<link ID>,<segment ID> ,<status><br><br>OK<br><br>If connection is not established, returns<br>ERROR   |
| Parameters  | <link ID> ID of the connection (0~4), for multi-connect<br><segment ID> segment ID got by <a href="#">AT+CIPSENDBUF</a> ;<br><status> TRUE, sent successfully; FALSE, send fail |
| Note  | Only keep status of the latest 32 segments at most.   |

## 9. AT+CIPBUFORESET – Reset segment ID count

| AT+CIPBUFORESET - Reset segment ID count |  |
|--|--|
| Single connection                        | (+CIPMUX=0)<br><b>AT+CIPBUFORESET</b>  |
| Multiple connection                      | (+CIPMUX=1)<br><b>AT+CIPBUFORESET=&lt;link ID&gt;</b>  |
| Response                                 | OK<br><br>If connection is not established or there are still TCP data wait for sending,<br>returns<br>ERROR |
| Parameters                               | <link ID> ID of the connection (0~4), for multi-connect  |



## 10. AT+CIPCLOSE – Close TCP, UDP or SSL connection

| AT+CIPCLOSE - Close TCP, UDP or SSL connection |  |
|--|--|
| Multiple connection                            | AT+CIPCLOSE=<link ID>  |
| Response                                       | OK<br>or<br>ERROR  |
| Parameters                                     | <link ID> ID no. of connection to close, when ID=5, all connections will be closed.<br>(ID=5 has no effect in server mode) |
| Single connection                              | AT+CIPCLOSE  |
| Response                                       | OK<br>or<br>If no such connection, returns<br>ERROR  |

## 11. AT+CIFSR – Get local IP address

| AT+CIFSR - Get local IP address |   |
|---------------------------------|---|
| Command                         | AT+ CIFSR   |
| Response                        | + CIFSR:<IP address><br><br>OK<br>ERROR   |
| Parameters                      | <IP address><br><br>IP address of ESP8266 softAP<br>IP address of ESP8266 station |
| Note                            | Only after ESP8266 station connected to AP, station IP can be got and inquired.   |



## 12. AT+CIPMUX – Enable multiple connections

| AT+ CIPMUX - Enable multiple connections or not |  |
|---|--|
| Example   | AT+CIPMUX=1  |
| Command   | AT+CIPMUX?   |
| Response  | + CIPMUX:<mode><br>OK  |
| Parameters                                      | <mode>0 single connection<br><mode>1 multiple connection   |
| Command   | AT+CIPMUX=<mode>   |
| Response  | OK<br>If already connected, returns<br>Link is builded   |
| Parameters                                      | The same as above.   |
| Notes   | 1. " <a href="#">AT+CIPMUX=1</a> " can only be set when transparent transmission disabled<br>( " <a href="#">AT+CIPMODE=0</a> " )<br>2. This mode can only be changed after all connections are disconnected.<br>3. If TCP server is started, has to delete TCP server first, then change to single connection is allowed. |



### 13. AT+CIPSERVER – Configure as TCP server

Server monitor will automatically be created when Server is created. When a client is connected to the server, it will take up one connection, be gave an id.

| AT+CIPSERVER - Configure as TCP server |  |
|--|--|
| <b>Example</b>                         | AT+CIPMUX=1<br>AT+CIPSERVER=1,1001   |
| <b>Command</b>                         | <b>AT+CIPSERVER=&lt;mode&gt;[,&lt;port&gt;]</b>  |
| <b>Response</b>                        | OK   |
| <b>Parameters</b>                      | <mode> 0 Delete server<br><mode> 1 Create server<br><port> port number, default is 333 |
| <b>Notes</b>                           | Server can only be created when <a href="#">AT+CIPMUX=1</a>                            |



#### 14. AT+CIPMODE – Set transfer mode

UART-WiFi passthrough mode (transparent transmission) can only be enabled in TCP single connection mode or UDP of which remote IP and port won't change (parameter <UDP mode> is 0 when using command "AT+CIPSTART" to create a UDP transmission).

During UART-WiFi passthrough transmission, if it is TCP connection and the TCP connection breaks, ESP8266 will keep trying to reconnect until "+++" is inputed to quit from transmission. After "+++", please wait at least 1 second before sending next AT command.

If it is a normal TCP transmission and TCP connection breaks, ESP8266 will prompt "[<link ID>] CLOSED", and won't try to reconnect. Users can call "AT+CIPSTART" to create a connection again if it's needed.

| AT+ CIPMODE - Set transfer mode |   |
|---------------------------------|---|
| Example                         | AT+CIPMODE=1  |
| Command                         | AT+CIPMODE?   |
| Response                        | + CIPMODE:<mode><br>OK                                    |
| Parameters                      | same as below   |
| Command                         | AT+CIPMODE=<mode>   |
| Response                        | OK<br>If already connected, returns<br>Link is builded    |
| Parameters                      | <mode>0 normal mode<br><mode>1 UART-WiFi passthrough mode |
| Notes                           | This configuration would <b>NOT</b> save into Flash.      |



## 15. AT+SAVETRANSLINK – Save transparent transmission link to Flash

| AT+SAVETRANSLINK - Save transparent transmission link to Flash |  |
|--|--|
| Example  | AT+SAVETRANSLINK=1,"192.168.6.110",1002,"TCP"  |
| Command  | AT+SAVETRANSLINK =<mode>,<remote IP>,<remote port>[,<type>][,<TCP keep alive>][,<UDP local port>]  |
| Response   | OK<br>or<br>ERROR  |
| Parameters   | <br><b>&lt;mode&gt;</b><br>0 : normal mode, cancel enter UART-WiFi passthrough mode when power on<br>1 : save UART-WiFi passthrough mode<br><b>&lt;remote IP&gt;</b> remote IP<br><b>&lt;remote port&gt;</b> remote port<br><b>[&lt;type&gt;]</b> TCP or UDP, default to be "TCP"<br><b>[&lt;TCP keep alive&gt;]</b> TCP keep alive, default to be disabled<br>0: disable TCP keep alive<br>1 ~ 7200: keep-alive detect time interval, unit: 500 ms<br><b>[&lt;UDP local port&gt;]</b> local port if enter UDP transparent transmission when power on. |
| Notes  | <ul style="list-style-type: none"><li>This command will save the UART-WiFi passthrough mode and its link into Flash user parameter area, ESP8266 will enter UART-WiFi passthrough mode since next power on.</li><li>As long as the IP, port numerical conformance to specification, we will save them to Flash</li></ul>   |



## 16. AT+CIPSTO – Set TCP server timeout

| AT+ CIPSTO - Set TCP server timeout |  |
|-------------------------------------|--|
| <b>Example</b>                      | AT+CIPMUX=1<br>AT+CIPSERVER=1,1001<br>AT+CIPSTO=10   |
| <b>Command</b>                      | <b>AT+CIPSTO?</b>  |
| <b>Response</b>                     | + CIPSTO:<time><br><br>OK  |
| <b>Parameters</b>                   | The same as below.   |
| <b>Command</b>                      | <b>AT+CIPSTO=&lt;time&gt;</b>  |
| <b>Response</b>                     | OK   |
| <b>Parameters</b>                   | <time> TCP server timeout, range 0~7200 seconds  |
| <b>Notes</b>                        | ESP8266 as TCP server, will disconnect to TCP client that didn't communicate with it even if timeout.<br><br>If AT+CIPSTO=0, it will never timeout. We don't recommend that. |

## 17. AT+PING – Function Ping

| AT+PING - Function Ping |  |
|-------------------------|--|
| <b>Example</b>          | AT+PING="192.168.1.1"<br>AT+PING="www.baidu.com"   |
| <b>Command</b>          | <b>AT+PING=&lt;IP&gt;</b>  |
| <b>Response</b>         | +<time><br><br>OK<br>Or<br>ERROR // means ping fail  |
| <b>Parameters</b>       | Param description<br><IP> : string, host IP or domain name<br><time> : response time of ping |



## 18. AT+CIUPDATE – Update through network

Firmware upgrade depends on network condition. It will return [ERROR](#) if upgrade fail, please wait a while.

- If using Espressif AT BIN (`\esp_iot_sdk\bin\at`), “[AT+CIUPDATE](#)” will download new AT BIN from Espressif Cloud.
- If using user-compiled AT BIN, users need to make their own “[AT+CIUPDATE](#)” to upgrade, Espressif provide a demo in `\esp_iot_sdk\example\at`. AT BINs on server have to be named as “user1.bin” and “user2.bin”

| AT+ CIUPDATE - update through network |   |
|---------------------------------------|---|
| Command                               | AT+CIUPDATE   |
| Response                              | +CIUPDATE:<n><br><br>OK   |
| Parameters                            | <n> 1 found server<br><n> 2 connect server<br><n> 3 got edition<br><n> 4 start update |

## 19. AT+CIPDINFO – Show remote IP and port with “+IPD”

| AT+CIPDINFO - Show remote IP and port with “+IPD” ( received data from network ) |   |
|--|---|
| Example  | AT+CIPDINFO=1   |
| Command  | AT+CIPDINFO=<mode>  |
| Response   | OK<br>Or<br>ERROR   |
| Parameters   | Param description<br><mode> 0: won't show remote IP and port with “+IPD”<br><mode> 1: show remote IP and port with “+IPD” |



## 20. +IPD – Receive network data

| +IPD - Receive network data |  |
|-----------------------------|--|
| Single connection           | (+CIPMUX=0)<br>+IPD,<len>[,<remote IP>,<remote port>]:<data>   |
| Multiple connection         | (+CIPMUX=1)<br>+IPD,<ID>,<len>[,<remote IP>,<remote port>]:<data>  |
| Parameters                  | <remote IP> remote IP, enabled by command "AT+CIPDINFO=1"<br><remote port> remote port, enabled by command "AT+CIPDINFO=1"<br><ID> id no. of connection<br><len> data length<br><data> data received |
| Notes                       | When the module receives network data, it will send the data through the serial port using +IPD command.   |



## 6. Appendix

ESP8266 AT commands below will save configuration parameters into flash:

| AT Command                                   | Example  |
|--|--|
| <b>Save into flash user parameter area</b>   |  |
| AT+UART_DEF                                  | AT+UART_DEF=115200,8,1,0,3                       |
| AT+CWDHCP_DEF                                | AT+CWDHCP_DEF=1,1                                |
| AT+CIPSTAMAC_DEF                             | AT+CIPSTAMAC_DEF="18:fe:35:98:d3:7b"             |
| AT+CIPAPMAC_DEF                              | AT+CIPAPMAC_DEF="1a:fe:36:97:d5:7b"              |
| AT+CIPSTA_DEF                                | AT+CIPSTA_DEF="192.168.6.100"                    |
| AT+CIPAP_DEF                                 | AT+CIPAP_DEF="192.168.5.1"                       |
| AT+CWDHCPS_DEF                               | AT+CWDHCPS_DEF=1,3,"192.168.4.10","192.168.4.15" |
| AT+SAVETRANSLINK                             | AT+SAVETRANSLINK =1,"192.168.6.10",1001          |
| <b>Save into flash system parameter area</b> |  |
| AT+CWMODE_DEF                                | AT+CWMODE_DEF=3                                  |
| AT+CWJAP_DEF                                 | AT+CWJAP_DEF="abc", "0123456789"                 |
| AT+CWSAP_DEF                                 | AT+CWSAP_DEF="ESP8266","12345678",5,3            |
| AT+CWAUTOCONN                                | AT+CWAUTOCONN=1                                  |

- Only if the configuration changes, we will write the new configuration into Flash.
- To 512KB+512KB Flash Map:  
user parameter area is **0x7C000 ~ 0x80000**, 16KB;
- To 1024KB+1024KB Flash Map:  
user parameter area is **0xFC000 ~ 0x100000**, 16KB;
- System parameter area is always the last 16KB of Flash.




## 7. Q&A

If you have any questions about AT Commands, please contact us ([support-at@espressif.com](mailto:support-at@espressif.com)) with information as follows:

- **Version info of AT** : Using "AT+GMR" to get the version info.

Hardware Module info: example Ai-thinker ESP-01

- **Screenshot or steps of the test steps**, for example:



- **Log**:

```
ets Jan 8 2013,rst cause: 1, boot mode: (3,3)

load 0x40100000, len 26336, room 16
tail 0
chksum 0xde
load 0x3ffe8000, len 5672, room 8
tail 0
chksum 0x69
load 0x3ffe9630, len 8348, room 8
tail 4
chksum 0xcb
csum 0xcb
SDK version: 0.9.1
addr not ack when tx write cmd
mode : sta(18: fe: 34: 97: d5: 7b) + softAP(1a: fe: 34: 97: d5: 7b)
```